

AWE

Pairing and Transaction User Guide

Updated on, by: 03/02/2025, HMS

Reviewed on, by: 05/02/2025, TB

mx51




Table of Contents

- System Requirements
- Pairing the Point-of-Sale (POS) to the EFTPOS Terminal

System Requirements

Systems	Requirements
Connectivity	Both the Point-of-sale (POS) system and EFTPOS Terminal need to be connected to the same Local Area Network
POS Version	5.30.0.0 and above
POS Operating System	Windows 10 and above
Integration Type	SPICE

Pairing the POS to the EFTPOS Terminal - *Setting up Spice* (1 of 7)


Steps	Example Screens
<p>1. Download Spice</p> <p>https://spice.integration.mspenv.io/latest.exe</p> <p><i>* Please see your POS provider for enabling Spice integration within the POS. Set up will vary depending on the POS provider.</i></p> <p>2. Spice will begin downloading. Once complete, select open in your toolbar or go to your PC downloads folder.</p> <p>3. When the program is run, there is no visible installation process and Spice should appear within a few seconds.</p>	 <p>The screenshot shows a dialog box titled "Minimum PC Specifications". It contains a bulleted list of requirements: "1.6 GHz or faster processor (32-bit or 64-bit)", "Windows 8 or newer", "2 GB Ram", and "Internet connection (will function offline)". Below the list is a "Download" button. At the bottom of the dialog, it says "Please contact your POS software provider to complete pairing."</p>

Pairing the POS to the EFTPOS Terminal - *Setting up Spice* (2 of 7)

Steps

4. You will be automatically directed to the about tab (end user licence agreement).

Example Screens






Pairing the POS to the EFTPOS Terminal - *Setting up Spice* (3 of 7)

Steps

5. On the EFTPOS terminal, Select **Menu**
Note: If there is no existing pairing, the "Manage POS pairing" button will show
6. Select **Manage POS pairing**
7. Select **+**

Example Screens



Pairing the POS to the EFTPOS Terminal - *Setting up Spice* (4 of 7)

Steps

8. Go to the **Status** tab on Spice.
9. On **Spice**;
 - o Select your **payment provider**, enter the details of the EFTPOS terminal and **enable Auto Address resolution**.

Example Screens

The screenshot displays the Spice application interface. The top navigation bar includes the 'Status' tab (highlighted with a red box), 'Transactions', 'Settlement', 'Settings', and 'About'. The main content area is titled 'EFTPOS Terminal Pairing' and contains the following fields and controls:

- Payment provider:** A dropdown menu with 'Gecko Demo Bank' selected.
- POS ID:** A text input field.
- EFTPOS address:** A text input field.
- Auto Address Resolution:** A toggle switch that is currently turned on (green).
- Pair:** A green button to initiate the pairing process.



At the bottom of the screen, it displays 'Version 3.1.1 - You're on the latest version!' with a refresh icon.

Pairing the POS to the EFTPOS Terminal - *Setting up Spice* (5 of 7)

Steps

10. Select **START** on the EFTPOS terminal and **PAIR** on Spice.

Example Screens







Pairing the POS to the EFTPOS Terminal - *Setting up Spice* (6 of 7)


Steps

11. Ensure the code displayed matches what is displayed on Spice and select **YES** on the EFTPOS terminal.
12. Select **FINISH** on the EFTPOS terminal.

Example Screens



Pairing the POS to the EFTPOS Terminal - *Setting up Spice* (7 of 7)

Steps	Example Screens
13. Select OK on Spice.	 A screenshot of a mobile device screen. The screen is white with a thin grey border. In the center, the text "Pairing Successful!" is displayed in a bold, black, sans-serif font. Below the text is a red rectangular button with rounded corners and the text "OK" in white, centered on the button. The button is highlighted with a red border.